

Kære Kunde

GODE RÅD OM BEHANDLING OG OPBEVARING AF UDENDØRS JULEBELYSNING

Placer ikke julebelysningen hvor der er meget åbent, og risiko for hård vind, eller storm (gælder lyskæder, og især flagstangs net)

Placer ej heller belysningen lige under eks. tagrender osv. hvor der kommer uhensigtsmæssigt meget vand, direkte på.

Udendørs julebelysning er IP44 godkendt til brug udenfor, men ikke vandtæt IP68 !

Eventuel isætning af plast spyd til lystrær osv. skal dette gøres forsigtigt, nedefra, så de ikke krænges, og knækker, og aldrig i frossen jord.

Vær forsigtig med ikke at krænge ledningen ved nedtagning. Tjek samtidig at løse dele, så som transformere er intakt, og også bliver tørt af.

Efter sæson afslutning, anbefales det, at tørre jule belysningen af, og at opbevare det på et tørt sted, og gerne i den originale emballage.

TIMER FUNKTION OG LYS VARIANTER

Hvis lyskæden er med **Timer**, og tændes f.eks. kl. 18.00 - så lyser den i 6 timer til kl. 24.00 og tænder automatisk igen næste dag kl. 18.

Ved dobbelt timer funktion, tænder den i mellemtiden igen fra kl. 06.00 til kl. 09.00.

Modeller med flere lysvarianter, vælges på batteri boksen ud fra tallene 1-8, hvor 8 er konstant lys

SIKKERHED !

Tilslut ikke belysningen før det er pakket helt ud.

Anvend kun det medfølgende tilbehør og adapter, eller tilsvarende originale dele, og adaptere fra VELI LINE

Ved eventuelt brud på ledningen, skal hele varen kasseres.

God fornøjelse med din udendørs julebelysning fra VELI LINE.

VELI LINE ApS
Gefionsvej 4
DK 3400 Hillerød

Dear Customer

GOOD ADVICE ON TREATMENT AND STORAGE OF OUTDOOR CHRISTMAS LIGHTING

Do not place the Christmas lights where it is very open and risk of strong winds or storms (this regards light chains, and especially flagpole net)

Also, do not place the lighting directly under gutters, etc. where there is an inappropriate amount of water, directly on.

Outdoor Christmas lighting is IP44 approved for outdoor use, but not waterproof IP68!

In the event of insertion of plastic spears - for light trees, etc. this must be done carefully, from below, so that they do not heel and break, and never in frozen soil.

Be careful not to tilt the cord when disassembling. At the same time, check that loose parts like the transformer is intact and dry.

After the end of the season, it is recommended to wipe the Christmas lights off, and to store it in a dry place, and preferably in the original packaging.

TIMER FUNCTION AND LIGHT OPTIONS

If the light chain is **with Timer, and is** switched on e.g. at 18.00 - then it lights up for 6 hours until kl. 24.00 and turns on automatically again the next day at. 18.00

With double timer function, it turns on again in the meantime from kl. 06:00 to 09.00.

Models with several light variants are selected on the battery box based on the numbers 1-8, where 8 is constant light.

SAFETY !

Do not connect the lighting until it is completely unpacked.

Use only the supplied parts, and adapter, or equivalent original parts and adapters from Veli Line.

In the event of a break in the cord, the entire item must be discarded.

Enjoy your outdoor Christmas light from VELI LINE

VELI LINE ApS
Gefionsvej 4
DK 3400 Hillerød